



SERVICE WALLS

USED AS SEPARATING WALLS TO ISOLATE AND SECURE
PLANT ROOMS FROM OTHER AREAS OF THE BUILDING

Hebel1159




VERTICAL CROSS SECTION DETAIL A-A



ISOMETRIC VIEW

NTS



DETAIL PLAN VIEW

SERVICE SHAFT WALL - OPTION 1					
CODE	APPLICATION	WALL THICKNESS	WALL HEIGHT 'H'	FRL ⁽⁶⁾	R+C ₁ ⁽⁸⁾
Hebel1159	BARE SHAFT	75mm	UP TO 4.65m HIGH	-/120/120	33

REFER TO DESIGN AND INSTALLATION GUIDES FOR HIGH RISE SERVICE SHAFT & SCISSOR STAIR WALLS (HELT 032) FOR MORE DETAILED INFORMATION

 CSR BUILDING PRODUCTS LTD Head Office: 7 TULLA, 20 DELANEY NORTHVALE NSW 2113 1300 654 320 A.B.N. - 55 008 631 396 P.O. BOX 289 448 WWW.HEBELBUILDING.COM.AU		 The power view to build 1300 654 320 A.B.N. 55 008 631 396		REVISION CODE	HEBEL SERVICE WALLS	DATE
Hebel1159		SCALE		1:5 @ A3	15 of 1	15.04.20
REVISION CODE		HEBEL CODE		ET	CW	C